




160x60 cm



TOUCH BUTTON




160x60 cm




TOUCH BUTTON


Manual for Rectangular Mirror



powercord place
back of mirror



powercord outer of
mirror



Necessary tools before Install



Impact drills


hammer

screw driver


meter

Installation step


How to Make holes on the wall




measure the exact distance between
two hookings



marking same distance on wall
as above drawing. make sure two
cross stay on horizon. then make
holes at cross points



put the setscrew inside wall



hang up mirror on setscrew

if you mirror has this function

Testing Mirror working



press both anti-fog key and light key to adjust time
and please note that time and temperature will be
auto-cycle displaying every 15 seconds