

29.3989

ROMBO-ECO



Intallation Guide

GUIDE D'INSTALLATION

Shower Column

Technical Data

Maximum operating pressure:	0.86Mpa
Recommend pressure:	0.35-0.55Mpa
Max.hot water temperature:	80°C
Recommend hot water temperature:	49-72°C

Recommended Tools for Installation:



Screwdriver



Hex Key



pencil



Drill



Tape measure
(3m-5m)



Drill bit
($\varnothing 6.5$)




Sealing Tape

Replacement Parts:

1. Thermostatic faucet	1PC
2. Rubber Washer	2PCS
3. Decoration Cover	2PCS
4. Brass Joint	2PCS
5. Hexagon socket screw	2PCS
6. Shower Tube	1PC
7. Fixing Parts and Hand shower holder	1PC
8. Self-tapping Screw	2PCS
9. Fixing Base	1PC
10. Plastic Screw	2PCS
11. Head shower	1PC
12. Filter Washer	3PCS
13. Shower Hose	1PC
14. Hand Shower	1PC



Parts Identification:

In order to make identifying all parts and components of the shower column easily and accurately, we have provided each part with a numeric code. Please make use of this code to reference parts and in the event you need to have a part replaced or ordered.




Basic Set Up:

Below is a visual step-by-step sequence of how to put the shower column's main components together




Positioning the column using user's height

Depending on your height, we recommend the shower head to be positioned approx. 300mm above your head. If you have several persons in your home who will use this shower column, measure the height of the tallest person and position the shower head 300mm over that height.



Preparing the proper position for your shower column


1. Installing the thermostatic faucet



2 Connect the shower tube with thermostatic faucet; Mark the two holes of fixing base by pencil.



3. Drill the two holes on the wall according to the marks, then install the fixing base.



4. Connect the shower hose with thermostatic faucet, then fix the fixing parts with fixing base by hexagon socket screw.

