




1200x900x1950mm



TECHNICAL DRAWING



INSTALLATION MANUAL





CR045-80120


CR045-90120

CR045-90140

CR045-90160



RoHS  ISO9001:2008






SIZE	L1	L2
1180-1200x780-800x1950	1175	775
1180-1200x880-900x1950	1175	875
1380-1400x880-900x1950	1375	875
1580-1600x880-900x1950	1575	875

Install the wall profile: according the line to install the profile notice: put the profile in middle of line.



Install the fixed glass: insert the fixed glass into wall profile.




Attention: Do not remove the Black corner protector until insert well the glass into the wall profiles and fit well to prevent glass broken and splitted.




3

Install the "L" guide rail .





4


install the decorate part and
Aluminum water-proof gasket.




5




Install the aluminum corner decorate part.




6




Install the door glass.



1. Install the water-proof gasket.
2. Install the magnetic stripe.
3. Install the handle.



Install the decorate profile:install the connect buckle,insert the decorate profile into buckle as picture shows, then install the top decorate cap.



Take glue:please keep dry until 24 hour.

